This Information Is Provided By

CBTricks.com

Royce 1-653B Service Manual

Liability of damages to any equipment is the sole responsibility of the user! Downloading, viewing, or using any information provided on these pages automatically accepts the user to the terms of this agreement!

Modifications are provided for information purposes only!

Supporters of CBTricks.com paid for the hosting so you would have this file.

CBTricks.com is a non-commercial personal website was created to help promote the exchange of service, modification, technically oriented information, and historical information aimed at the Citizens Band, GMRS (CB "A" Band), MURS, Amateur Radios and RF Amps.

CBTricks.com is not sponsored by or connected to any Retailer, Radio, Antenna Manufacturer or Amp Manufacturer, or affiliated with any site links shown in the links database. The use of product or company names on my web site is not endorsement of that product or company.

The site is supported with donations from users, friends and selling of the Site Supporters DVD's to cover some of the costs of having this website on the Internet instead of relying on banner ads, pop-up ads, commercial links, etc. Thus I do not accept advertising banners or pop-up/pop-under advertising or other marketing/sales links or gimmicks on my website.

ALL the money from donations is used for CBTricks.com I didn't do all the work to make money (I have a day job). This work was not done for someone else to make money also, for example the ebay CD sellers.

All Trademarks, Logos, and Brand Names are the property of their respective owners. This information is not provided by, or affiliated in any way with any radio or antenna Manufacturers.

Thank you for any support you can give.

For information on how to Support CBTricks.com http://www.cbtricks.com/support/

Fig 1







Fig 2

TOP VIEW




BACK VIEW





TROUBLE-SHOOTING CHART



1-653B MAIN CHASSIS PARTS LIST

Semiconductors DM1
CONTROLS VRMI Squelch Control 10K ohm 4-210 VRM2 Volume Control 50K ohm 4-112 SM2 PA-CB switch SM3 ANL switch CASE PARTS Main Case 3-144 Front Panel Meter Fixing Metal 6-104 Meter Fixing Metal 6-104 Module Rear Support Metal 6-105 Speaker Extension 5-115 Mic Jack 5-501 Antenna Jack 5-502 Ext. Speaker/PA Jack 5-503 Mounting Bracket 3-412 Mic Hanger 3-428 Wingbolt (Large) 3-437 Wingbolt (Small) 3-436 D.C. Input Jack 5-505 Channel Knob and Disc 3-312 Volume/Squelch Knob 3-312 PA/CB/ANL Knob 2-0031 COILS — INDUCTORS TM1 Choke 2-0031 CAPACITORS CM1 01μF CM2 .022μF <tr< td=""></tr<>
Main Case 3-144 Front Panel Meter Fixing Metal Channel Lamp Fixing Metal 6-104 Module Front Support Metal 6-105 Speaker Extension 5-115 Mic Jack 5-501 Antenna Jack 5-502 Ext. Speaker/PA Jack 5-503 Mounting Bracket 3-412 Mic Hanger 3-428 Wingbolt (Large) 3-437 Wingbolt (Small) 3-436 D.C. Input Jack 5-505 Channel Knob and Disc 3-355 Channel Indicator Disc 3-355 Volume/Squelch Knob 3-312 PA/CB/ANL Knob 2-0031 COILS — INDUCTORS TM1 Choke 2-0031 CAPACITORS CM1 .01μF CM2 .022μF CM4 1,000μF CM5 .039μF
Module Rear Support Metal $6-105$ Speaker Extension $5-115$ Mic Jack $5-501$ Antenna Jack $5-502$ Ext. Speaker/PA Jack $5-503$ Mounting Bracket $3-412$ Mic Hanger $3-428$ Wingbolt (Large) $3-437$ Wingbolt (Small) $3-436$ D.C. Input Jack $5-505$ Channel Knob and Disc $3-331$ Channel Indicator Disc $3-331$ Volume/Squelch Knob $3-312$ PA/CB/ANL Knob COILS — INDUCTORS TM1 Choke $2-0031$ CAPACITORS CM1 01μ F CM2 $.022\mu$ F CM4 $1,000\mu$ F CM5 $.039\mu$ F
TM1 Choke 2-0031 TM2 Choke 2-0031 CAPACITORS CM1 $.01\mu$ F CM2 $.022\mu$ F CM4 $1,000\mu$ F CM5 $.039\mu$ F
CAPACITORS CM1 $.01\mu$ F CM2 $.022\mu$ F CM4 $1,000\mu$ F CM5 $.039\mu$ F
CM7

Description	ı	Part #	
RESISTORS	}		
RM9-13	10K		
RP1	2.2K (on front panel)		
RP2	150 Ω (on front panel)		
THMI	TD-5-165 (thermister)		
MISCELLANEOUS			
Speaker		.5-103	
RLM Relay		.4-607	
	ter Lamp		

.

GENERAL SPECIFICATIONS

1. Semiconductors : 25 transistors, 21 diodes, 4 integrated circuits, and 1 thermistor.

2. Self-Contained Speaker : 3 inch, 8 ohm voice coil.

3. Microphone : Dynamic microphone with push-to-talk switch, 500 ohms.

4. Controls, Indicators and : Volume control with power on-off switch

Connectors : Variable Squelch Control.

: Channel Selector.

: Illuminated Channel Indicator.

: Pushbutton A.N.L. : Pushbutton PA-CB.

: Coaxial type antenna connector.

: External Speaker Jack.

: Public Address Speaker Jack.

: Microphone Connector.

5. Power Supply :13.8 Volts DC (positive or negative ground).

6. Cabinet Description : Plastic front with chrome plating and vinyl coated

metal cabinet.

7. Dimensions $: 8-7/8" D \times 7" W \times 2-1/4" H.$

RECEIVER

1. Frequency Range (MHz) : 26.965-27.255

2. Sensitivity : 0.5 uV for 10 db S+N/N 3. Selectivity : 5 KHz minimum at 6 db down

4. Adj. Channel Rejection : More than 60db.

5. Audio Power output at 8 ohms : More than 4W at 10% distortion

6. Audio fidelity (1KHz=0db, :400Hz-2,000Hz

6db down)

7. A.G.C. figure of merit : More than 80db

(Input 94db for 10db range)

8. Squelch sensitivity (Threshold) : Less than 0.5uV9. Spurious Rejection : More than 45db

TRANSMITTER


1. Frequency Range (MHz) : 26.965-27.255 2. RF Output Power : 4W average

3. Modulation Capability : 100%

4. Spurious Suppression : More than 50db

5. Frequency Tolerance $:\pm 0.005\%$

WIRING DIAGRAM



1-653B SERVICE NOTES

- 1. After localizing a defective module, it will be necessary to remove the module front support metal before the module can be extracted (see Figure 1).
- Take particular care in desoldering and resoldering on the main chassis. Engineering tests indicate an average of five solderings before damage results to the foil patterns.
- 3. If it becomes necessary to remove boards U1 or U2, it is also necessary to remove the entire speaker assembly on some models.
- 4. The PLL oscillator module is not designed as a field-serviceable unit. Parts will not be made available, so please do not attempt repair. Return defective modules for replacement.