

SBE FORMULA D TOUCH COM
51 CHANNEL CONVERSION

- (1) Remove unit from cabinet and locate pins of integrated circuits shown.
- (2) Remove PA speaker jack from rear of unit or drill a hole in the side of the chassis and mount the switch.
- (3) Solder three wires to the pins of the switch, and wire unit as shown.

NOTE: More information and a better view is shown in this book under Formula D, the basic PLL board is the same. The frequencies can be obtained from the chart.

