

PRESIDENT - JOHN Q./HONEST ABE/ZACHARY T./
TEDDY R.
70 PLUS CHANNEL CONVERSION

1. Remove the unit from its cabinet and locate the clear ribbon cable from the channel selector. This cable connects to the circuit board as shown in the figure.
2. Mount a SPST switch on the unit in a convenient spot and solder two wires to the switch and the other ends to the two parts as shown in the figure.
3. To use the new channels, flip the switch on and the channel selector to channel 4. This will be channel 40 and continue upwards to the 70's .

MODULATION INCREASE

Turn VR-5 to its fully counter-clockwise position, on all units except the JOHN Q., in which case it is labeled as RT-4

*NOTE: When soldering the PLL unit as shown in the figure, make sure that all wiring is correct and not shorting to any other pins BEFORE APPLYING POWER, as very serious damage can result to the PLL unit.

