

# SPECIFIC INSTALLATION INSTRUCTIONS (CONT)

## FOR VSB-1

### PRESIDENT HONEST ABE -

Compressor- Remove D13 and D12. Solder BLACK lead to where cathode of D13 was and the WHITE lead to where cathode of D12 was.

Expander- Remove C29. Insert the BLACK lead towards R26, and the WHITE lead in the other hole.

PREAMP RECOMMENDED

### PRESIDENT THOMAS J. 1013001 -

Compressor- Remove C37. Solder the BLACK wire towards the common of TR17, and the WHITE wire towards R48. Remove TR18.

Expander- Remove C33. Solder the BLACK wire towards D7, and the WHITE wire towards C34.

PREAMP RECOMMENDED

### PRESIDENT WASHINGTON(1001002)/NEW MCKINLEY -

Compressor- Remove C83. Solder the BLACK wire to the positive side of the hole, and the WHITE wire to the other side, towards TR27. Remove TR32.

Expander- Remove <sup>C28</sup>~~C110~~. Solder the BLACK wire towards the collector of ~~TR36~~, and the WHITE wire towards ~~R36~~ <sup>R36</sup>.  
~~pin 4 of IC4. TR13~~

NO PREAMP

### PRESIDENT VEEP 1014001 -

Compressor- Remove C47. Solder the BLACK wire to hole by TR9, and the WHITE wire towards R27. Remove TR8.

Expander- Lift the brown wire off the volume control. Connect brown and BLACK wires together. Solder the WHITE wire to volume control.

PREAMP RECOMMENDED