

PACE 8193 CCI3001

SLIDER MOD:

1. Remove D8.
2. Remove D9.
3. Solder a piece of hook-up wire in the hole where the cathode (banded end) of D9 was.
4. Solder the other end of the wire to the emitter of Q18.

The Pin Out of the CCI3001 is below:

1. F. in.
2. + DC.
3. 1 Ref. OSC. input.
4. Ref OSC. output.
5. Ground.
6. Loop Filter.
7. Loop Filter.
8. D.O.
9. Phase detector output
10. T/R Switch.
11. P5 MSB.
12. P4.
13. P3.
14. P2.
15. P1.
16. P0 LSB
17. Loop Filter
18. Loop Filter