

Kenwood TS-940S, "Complete" TX/RX Modification
by R.S.

CAREFUL..... OR YOU WILL END UP WITH A \$2,000 PAPERWEIGHT.

1. Remove top and bottom covers. Remove screws which hold the front of the radio to the cabinet. Lay the front down CAREFULLY!
2. Locate digital-B-unit (X54-1840-00), see large picture below..
3. Locate diode D130, is next to IC109 - carefully clip or remove.
4. Locate diode D135, is next to IC112 - carefully clip or remove.
5. Modification is now complete; unit will transmit across the entire readout range. CAREFULLY reassemble unit, use extra caution - don't pinch any wires....

