

SBE 45CB TRINIDAD III

Adjust L305, L308, L309 for maximum AM power.
Adjust R226 for 100% modulation.
Adjust R404 for 13.8 volts.
R319: RF meter adjustment
R324: SWR meter adjustment
R128: S meter adjustment

SBE MODEL SBE42CB CORTEZ 40

Adjust L304, L306 for maximum RF power.
Adjust VR203 for 100% modulation.
VR301: RF meter adjustment
VR101: S meter adjustment
Connect pins 8 and 9 together for new frequencies IC401
(SM5107)

SBE 26CB1A

Adjust L6, L*, and L9 for maximum RF output.
Adjust VR9 for 100% modulation.
VR6: RF meter adjustment
VR7: S meter adjustment

SEARS 663.38070700

Adjust VR2 for 100% modulation.
Adjust L15, L12, and L11 for maximum RF output.
VR205: RF meter adjustment
VR204: S meter adjustment
Connect pin 19 of IC3 D858 to pin 21 for more
frequencies.

SEARS 934.38120700

Adjust T703, T704, and T705 for maximum RF power.
Clip D501 for 100% modulation.
RT2: RF meter adjustment
RT1: S meter adjustment

WARDS GEN-775A

Adjust L209, L210, and L211 for maximum RF power.
Adjust VR206 for 100% modulation.
VR205; RF power meter adjustment