

R/S-1175 (Noise Cancelling Amp. Mic.) "EXPORT" Hook-ups.

Note: (*) - If hum or squeal appears when wiring, may have to be removed.

Chart #1

<u>Unit</u>	<u>Old Wiring</u>	<u>New Wiring</u>
Superstar 120 (AM/FM & AM) Pacific 800 SSB Stalker 9FM & 9FDX Grant Jackson Cobra 148GTL-DX (Early and Late)	1. Shield, Ground 2. Audio 3. Normally Open 4. Normally Closed	1. Shield, Blue (*) 2. White 3. Red 4. Black

Chart #2

<u>Unit</u>	<u>Old Wiring</u>	<u>New Wiring</u>
Palomar, Colt, and Lafayette 2400 Ham Inter. Multimode 3; M788 Superstar 2000 (Both versions) NATO 2000 Major M-120 Tristar 727 Superstar 95 Midland 2001 (Export) Colt 510 Commtron XII	1. Audio 2. Shield, Ground 3. Normally Closed 4. Normally Open	1. White 2. Shield, Blue (*) 3. Black 4. Red

Chart #3

<u>Unit</u>	<u>Old Wiring</u>	<u>New Wiring</u>
Marko CB-444	1. Audio 2. Normally Open 3. Shield, Ground 4. No Connection 5. Normally Closed	1. White 2. Red 3. Shield, Blue (*) 4. No Connection 5. Black

R/S-1175 "Export" Hook-ups (Cont.)

Chart #4

Note: External Volume Control is Disabled. (*)

<u>Unit</u>	<u>Old Wiring</u>	<u>New Wiring</u>
Sommerkamp TS-340DX(*) Globephone GS-480DX(*)	1. Shorted to Pin 3	1. Short to Pin 3
	2. Ext Vol. Control	2. No Connection
	3. Shorted to Pin 1	3. Shorted to Pin 1
	4. Audio	4. White
	5. Ext Vol. Control	5. No Connection
	6. No Connection	6. No Connection
	7. Normally Open	7. Red
	Case-Shield, Ground	Case-Shield, Blue (*)

Chart #5

<u>Unit</u>	<u>Old Wiring</u>	<u>New Wiring</u>
Superstar 360 (AM/SSB/CW)	1. Audio	1. White
	2. Shield, Ground	2. Shield, Blue (*)
	3. Normally Closed	3. Black
	4. Ground	4. No Connection
	5. Normally Open	5. Red

Units not listed in charts haven't schematic to work with. If you have unit that needs wiring for, be patient - maybe someone will send in the schematic.

This chart will not be repeated in future volumes, but reference back to it will be made. Additional chart/s will be added if needed.