

## **THE ICOM IC-765 MARS MOD**

### **THE ICOM IC-765 MARS MOD**

---

(1) Remove or cut D53 from Matrix board. Diode is next to S36/37 on front of Rig, visible from the bottom.

### **THE KENWOOD TS-140 MARS MOD**

---

- (1) Locate Control board on bottom.
- (2) Remove or cut D31.
- (3) Reset microprocessor.

### **TS-140S 11MTR MOD**

---

#### **● BILL G.**

Clip D29 & D31.

### **THE KENWOOD TS-930S GENERAL XMIT**

---

#### **● RAYS RADIO**

- (1) Remove transceiver top cover. (8 screws).
- (2) Remove four screws from speaker mounting and top panel assembly.
- (3) Swing the assembly away and unplug the red, blk battery backup leads.
- (4) Jumper the following pins,
  - a.IC21 Pin 12 to IC11 Pin 9
  - b.IC22 Pin 12 to IC12 Pin 9
  - c.IC23 Pin 12 to IC24 Pin 8
- (5) Replace speaker assembly and top cover. Happy DXing.....

### **THE KENWOOD TS-940S GENERAL XMIT**

---

#### **● RAYS RADIO**

- (1) Remove both covers from transceiver.
- (2) Locate the digital unit B. (Closest to front panel)