

Consumer Response Group

6500 W. Cortland Street * Chicago, IL 60707 * Phone: 773-889-8870 * FAX: 773-622-2269

September 28, 2001

Page 1 of 1

TECHNICAL SERVICE BULLETIN 10007

- **MODEL(S):** All 148s with front-mount microphone.
- **DESCRIPTION:** Cobra has switched to a different type of potentiometer for the volume and RF Gain controls. The old potentiometer is round, the new one is square. The potentiometer mounts on a small PC board. The new potentiometers will not fit on the older PC boards.
- ACTION: When replacing the round potentiometers with the square ones, it will be necessary to use the new-style PC board that comes with the potentiometer. Simply transfer the wires from the old board to the new board. The wiring configuration is exactly the same, so just move the wires to the same corresponding position from the old board to the new board.

ADJUSTMENTS: None.

NOTES:Old round RF Gain control:008-073-N-001 (not available)Old round volume control:008-074-N-001 (not available)New square RF Gain control:008-025New square volume control:008-026PCB for new RF Gain control:300-001PCB for new volume control:300-002