

Consumer Response Group

6500 W. Cortland Street * Chicago, IL 60707 * Phone: 773-889-8870 * FAX: 773-622-2269

March 12, 2008

Page 1 of 2

TECHNICAL SERVICE BULLETIN 10058

MODEL(S):	CB model 29 (all versions with talk-back)
DESCRIPTION:	How to increase the volume of the talk-back.
ACTION:	Install a jumper from the top of R21 to the top of R77. This will effectively reduce the resistance of R21 to zero ohms, increasing the maximum volume of the talk-back function. The picture on page 2 shows the location of R21 and R77.
ADJUSTMENTS:	None
NOTES:	If the talk-back volume is turned too high, acoustic feedback can occur which will cause a squealing noise. The solution is to turn down the talk-back volume.

Note: In the photo below, the wiring bundle was moved for clarity. It is not necessary to move the

