This Information Is Provided By



### Craig L150 Service Manual

# Liability of damages to any equipment is the sole responsibility of the user! Downloading, viewing, or using any information provided on these pages automatically accepts the user to the terms of this agreement!

#### Modifications are provided for information purposes only!

Supporters of CBTricks.com paid for the hosting so you would have this file.

CBTricks.com is a non-commercial personal website was created to help promote the exchange of service, modification, technically oriented information, and historical information aimed at the Citizens Band, GMRS (CB "A" Band), MURS, Amateur Radios and RF Amps.

CBTricks.com is not sponsored by or connected to any Retailer, Radio, Antenna Manufacturer or Amp Manufacturer, or affiliated with any site links shown in the links database. The use of product or company names on my web site is not endorsement of that product or company.

The site is supported with donations from users, friends and selling of the Site Supporters DVD's to cover some of the costs of having this website on the Internet instead of relying on banner ads, pop-up ads, commercial links, etc. Thus I do not accept advertising banners or pop-up/pop-under advertising or other marketing/sales links or gimmicks on my website.

ALL the money from donations is used for CBTricks.com I didn't do all the work to make money (I have a day job). This work was not done for someone else to make money also, for example the ebay CD sellers.

All Trademarks, Logos, and Brand Names are the property of their respective owners. This information is not provided by, or affiliated in any way with any radio or antenna Manufacturers. Thank you for any support you can give.

> For information on how to Support CBTricks.com http://www.cbtricks.com/support/

# SERVICE MANUAL

# 

# L 150

#### **40-CHANNEL MOBILE CB TRANSCEIVER**

#### WARNING

Replacement or substitution of IC's, crystals, transistors, regulator diodes, or any other part of a specialized nature with parts other than those recommended by Craig may cause the operator to be in violation of the Type Acceptance requirements of Part 2 of the Rules.

FCC Rules require that ALL transmitter section adjustments, other than those supplied by Craig as operating controls, be made by or under the immediate supervision of the holder of an FCC First or Second Class Radio-Telephone Operator's License.

#### SPECIFICATIONS

"The specifications for this product were determined and are presented in accordance with specification standards established by the Ad Hoc Committee of Car Stereo Manufacturers."

#### RECEIVER

SENSITIVITY A	M: Better than 0.5	5 uV for 10 dB (S+N)/N 7 KHz @ -6.0 dB
AGC		output less than 10 dB
SQUELCH	Adjustable, three	shold less than 0.5 uV
IMAGE REJECTI	ON	ight, more than 250 uV Better than 70 dB
IF REJECTION ADJACENT CHAN		an 60 dB @ 10.695 MHz Better than 60 dB
IF FREQUENCY NOISE BLANKER		AM: 10.695 MHz
OUTPUT POWER		RF parallel gate type 4 W at 10 % THD

#### GENERAL

CHANNELS	40 AM
FREQUENCY RANGE	26,965 to 27,405 MHz
FREQUENCY TOLERANCE	+0.005 % from -30° C to +50° C
FREQUENCY STABILITY	+0.001 %
POWER SOURCE	13.8 Vdc pos. or neg. ground
CURRENT DRAIN; Receive	: 0.7 A @ maximum audio output
	0.3 A standby (no signal)
TRANSMI	T: ĂM full 1.5 Á
and the second	

#### TRANSMITTER

RF POWER OUTPUT MODULATION CAPABILITY		AM: 4 W 100 %
SPURIOUS ATTENTUATION 60 OUTPUT IMPEDANCE	dB	minimum 50 Ohm

NOTE: Description and Data Subject to Change Without Notice.


PAP	RTS PRICE L	IST	SUBJECT TO CHANGE WITHOUT NOTICE. USE ALL AVAILABLE NUMBERS AND COMPLETE DESCRIPTION WHEN ORDERING, INCLUDING MODEL NUMBER			
	DESCRIPTION	MFR's SUGG RET. PRICE	REF. No.	CRAIG KEY No.	DESCRIPTION RET	's SUGG . PRICE
L150001 L150002 L150507 L150395 XFU002 L150004 4101033 L150396 L150100 L150101 L150718	Individual Carton Carboard Sleeve Styrofoam Packing Microphone (Complete) Mounting Bracket (Black Box) Spare Fuse, 2A Mounting Hardware Kit D.C. Power Plug w/Cord Bracket, Mic Mounting External Spkr Patch Cord Relay Control Patch Cord Relay Box (Complete)	3.30 .80 1.65 104.90 1.15 1.00 2.35 3.50 .55 3.00 3.00 24.20	<b>CA</b> 1 2 3 4 5 6 7 8 9 10 11	BINET NSP NSP L150395 NSP L150102  NSP NSP	& CHASSIS(BLACK BOX Chassis, Main Chassis, Front Cover, Top & Bottom Mounting Bracket Model No./FCC/Serial No. Plate Label, Function Index PH Screw, Plastic M3x6 PH Screw, Plastic M3x8 PH Screw M3x5 Heat Sink Rivet	)

### A PRODUCT OF CRAIG CORPORATION

REF. No.	CRAIG KEY No.	DESCR	IPTION			s SUGG PRICE
САВ	INET &	CHAS	SIS (BL	ACK BOX c	ontinue	d)
J3 J4 J5 PC590	L150004 L150396 L150090  L150212  L150800 MB3712 L150607 L103607 L103607 L103607 L103608 4101027 NSP L150517 2SC2028 2SC2029 NSP	Brack "L" M RH Ta Lock RH Ta Star Hex N 6 Lea I.C. Socke Soc	pp Screw Washer Bolts ut d Flexibl (AF POWEF t, Microp ctor, Coa t, Extern	Mounting M3.5x8 M3.5x8 M5x10 M5 M5x8 M3 M3 M5x8 M3 M3 M5x8 M3 M3 M3 M3 M3 M3 M3 M3 M3 M3 M3 M3 M3	ctor na sk sk pr	2.35 .75 .25 .25 .25 .25 .25 .25 .25 .25 .25 .2
	BINET			IS(RELA	Y BOX)	
105 106 107 108 J501 J502 J503 J504 PC620	L150718 L150050 L150050 L150380 L150330 L150231  L150608 L103609 T615608 T615620 L150518 L150719	Top C Botto Clamp Bushi Stud, PH Sc Hex N PH Sc Socke 9P PW 9P PW PCB w	m Cover , 9P Conr ng, Ext S Mtg Spac rew M3 rew M3 t, Relay t, Exterr R/SP Conr R/SP Conr /Como, RE	nector Sp Jack Ser Sx10	SPK) )	24.20 1.65 2.45 .55 .25 .25 .80 .75 7.25 6.20 21.40 19.70
	BINET			IS (REM		
* ** 250 251 252 253 254 257 258 257 258 257 258 257 258 259 260 261 262 263 264 266 266 266 266 267 268 269 277 278 277 278 277 278 259 260 261 262 263 264 266 267 268 269 277 278 277 278 277 278 259 260 261 262 263 264 266 267 277 278 277 278 265 266 267 268 269 260 261 266 267 268 269 270 277 278 277 278 269 260 261 262 264 266 267 277 278 277 278 277 278 269 260 277 277 278 277 268 269 270 277 277 278 277 278 269 270 277 277 278 277 278 269 270 277 278 277 278 269 270 277 277 278 277 278 269 270 277 277 277 277 277 277 277	L150507 L150061 NSP NSP NSP NSP NSP L150702 L150430 L150430 L150430 L150430 L150432 L150420 L1505062 L150432 L150520 L150531 L1505570 NSP L150571 NSP L150381 L150570 L150381 L150571 NSP	Assy, Front Windo Dust Wide Model Optic Speak Front Back Assy, Back Assy, Back Mic H Butto Sw, 1 Cushi Knob, PH Ta Star PH Ta Slide VR 50C Grour PH Ta Clamp PH Ta Clamp PH Ta Clamp PH Ta Clamp PH Ta	er Cover er/Mic E cushion Cushion Panel langer Kno n, TX/RX CVRX Sel on, TX/RX VOL & Si pp Screw Washer app Screw & SW, CH J SK Ohm, Vi DK Ohm, Si d Lug app Screw coiled app Screw Channel	ANEL Display beaker 11 te r, Ch Displ lement Cable w/16P ob Select Sw ect X SW Mtg QUEL Cont M3.1x16 M3x8 M2.6x6 9/CH Lock/A 0LUME Cont QUELCH Cont QUELCH Cont QUELCH Cont QUELCH Cont QUELCH Cont M1 7x4 Cable M2 6x10 Indicator (I ICROPHONE	Plug	104.90 6.35   6.65 .40 27.50 2.30 2.30 2.30 2.50 2.55 .25 2.55 2.55 2.15  2.55 2.55 .25 2.55 .25 2.55 .10 1.00
REF. No.		RAIG Y No.	DESCRIP	TION		's SUGG . PRICE
CO	ILS, T	RIMI	MERS	& XFOF	RMERS	5
CF1 CF2 L1 L2 L3,4	L10 L10 L10	03670 03671 04670 04671 03675		Filter 10 Filter 455	(FL048)	1.40 6.45 .90 .90 .90
NO		SP;Non	Serviceat	ole Part		

REF.	CRAIG		s SUGG
	KEY No		PRICE
L6	L103678	S & XFORMERS (continue Trimmer (LA204)	.85
L7 L8 L9 L10 L11 L12 L14 L15 L16 L17 L18 L17 L18 L19 L20 RY1,2 RY501 T1 T2 T301	L103673 L150670 S609680 L104677 L104678 L104678 L104680 L103683 L103684 L103684 L103684 L103684 L150720 L150642 L150641 L150642	Trimmer (LA204)   Trimmer (LA276)   Trimmer (LA276)   Coil 100uH (LZ016)   Trimmer (LA165)   Trimmer (LA201)   Trimmer (LA088)   Trimmer (LA088)   Trimmer (LA038)   Trimmer (LA033)   Trimmer (LC072)   Coil (LE093)   Trimmer (LC072)   Coil (LE093)   Trimmer (LC072)   Relay SW (RL031)   Relay SW, RADIO/CB (RL033)   Coil, AF Choke (TF083)   Output Transformer (TF130)	
		OUS ELECTRICAL	
FC1 J1 J2 J3 J4 J5 J301	L150800 L150607 L103607 L103609 L150608 4101027 L150620	6 Lead Flexible Cable Socket, Microphone Conn Connector, Coaxial Antenna Socket, External Spkr Jack Socket, Relay Control Jack Socket, D.C Power Conn Assy, Coiled Cable w/16P Plug	.65 5.85 1.80 .75 .80 1.75 27.50
J501 J502 J503 J504 MIC1 MIC/SP P5 PC590 PC592 PC620 PC592 PC620 PCMIC RY1,2 RY501 S301 S301 S303 S303 S304 S305	L150608 L103609 T615608 T615602 L150507 L150507 L150517 L150518 L150519 L150720 L150719  L150531 L150531 L150531 L150531	Socket, Relay Control Jack Socket, External Spkr Jack 9P PWR/SP Conn(EXT SPK) 9P PWR/SP Conn(BADIO IN)	80 75 725 620 104.90 6.65 3.50 21.40 55.60 19.70 2.50 2.50 2.50 5.00
S306 VR1 VR2 VR301 VR301 VR302 X1	L150530 L104590 L132590 L132592 L150570 L150571 L150571 L103722	Push SW, TX/RX Select Semi-Fixed Res 500 0hm Semi-Fixed Res 1K 0hm Semi-Fixed Res 100K 0hm VR 10K, V0LUME Cont SW, POWER 0n/Off VR 50K, SQUELCH Cont Crystal, 10 240 MHz	1.85 .65 .70 .85 2.15 2.15 4.55
SEMIC	ONDUC	CTORS	
D1,2,3,8, 501, D4,5,6,7, 9,11,12, 13,14,15, 17,19,20, 23,24,302	IN4003	Diode	.65
D16 D21 D301 D303 D304 IC1 IC2 IC3 IC301 TR1 TR2	1 S2075K RD9.1EB1 RD5.1EB2 1 S2688EA TLRG101 0.525.1U UPD2814C TA7310P MB3712 UPD2803C 2SC763 2SK19	Diode Zener Diode Zener Diode Vari-Cap Diode LED, TX/RX Indicator Zener Diode LED, CHANNEL Indicator I.C. (PLL) I.C. (TX MIX) I.C. (AF POWER) I.C. (CH SELECT) Transistor FET	.45 .40 1.05 2.05 9.15 10.90 1.75 4.500 35.50 4.40
TR3,4,5, 6,18,19, 20,21, 22,24	25C710	Transistor	1.15
22,24 TR7,8,9, 10,12,13	2SC711	Transistor	.95
14,17 TR11 TR16,23 TR25 TR26 TR301	2SD355 2SA628 2SC2028 2SC2029 2SC1815	Transistor Transistor Transistor Transistor Transistor Transistor	1.50 .95 1.65 2.90 1.15

#### RELAY SWITCH PCB LAYOUT with WIRING DIAGRAM





#### ALIGNMENT PROCEDURES

STEP	SET TO	CONNECTIONS	ADJUST	ADJUST FOR
P	L.L. CIRCU	Т	l	
1	Channel 19. RX Mode.	Oscilloscope To Pin #22 Of I.C. 1 (TP 1).	L8	Maximum Indication On Oscilloscope.
2	Channel 40. TX Mode. No Modulation.	D.C. Volt Meter To Pin #19 Of I.C. 1 (TP 2).	L10	Reading Of Approx- imately 4.0 V.
TF	RANSMITT	ER		
1	Channel 19. TX Mode. No Modulation.	RF Wattage Meter To Antenna Jack (J2).	L12, 13	Maximum Indication On RF Wattage Meter.
2	Same As Step 1	Same As Step 1.	L14, 15, 17	Same As Step 1.
3	Same As Step 1	Same As Step 1.	L17	Nominal 3.8 W Of RF Output Power.
4	Repeat Steps 1,	2 & 3 To Insure That Adjustments Made Are Correct.		
5	Channel 19. 1 KHz (120mV) Applied Through Mic Input.	Signal Generator To Mic Jack (J1). Oscilloscope To Antenna Jack (J2) Through 50 Ohm Load And Attenuator,	VR2	95% Modulation.
6	All Channels. TX Mode. No Modulation.	Frequency Counter To Antenna Jack (J2) Through 50 Ohm Load And Attenuator.		Check All Channels For Correct Fre- quency Operation.
RI	ECEIVER			
1	Volume; MAX. Squelch; MIN.	Signal Generator To Antenna Jack (J2); (27.185 MHz). VTVM To EXT. SPKR Jack (J3)	L1, 2, 3, 4, 6, 7, 11	Maximum Audio Output.
2	Same As Step 1	Same As Step 1.	VR1	1.4 V Reading On VTVM. S/G Output Level Of 0.5 uV.
3	Volume; MAX. Squelch; MAX.	Same As Step 1.	VR3 (Squelch)	1.4 V Reading On VTVM. S/G Output Level Of 700 uV


TEST EQUIPMENT REQUIRED

- a) Oscilloscope b) D.C. Volt Meter c) VTVM d) RF Wattage Meter e) Frequency Counter f) 50 Ohm Dummy Load g) Signal Generator







#### **BLOCK DIAGRAM**




#### Schematic Diagram, REMOTE MICROPHONE



## CABINET & CHASSIS, RELAY BOX



**CABINET & CHASSIS, REMOTE MICROPHONE** 



## CABINET & CHASSIS, BLACK BOX

