

Someone who wanted to help you repair your equipment scanned this manual.

If you would like to help us put more manuals online support us.

Supporters of CBTricks.com paid for the hosting so you would have this file.

CBTricks.com is a non-commercial personal website was created to help promote the exchange of service, modification, technically oriented information, and historical information aimed at the Citizens Band, GMRS (CB "A" Band), MURS, Amateur Radios and RF Amps.

CBTricks.com is not sponsored by or connected to any Retailer, Radio, Antenna Manufacturer or Amp Manufacturer, or affiliated with any site links shown in the links database. The use of product or company names on my web site is not endorsement of that product or company.

If your company would like to provide technical information to be featured on this site I will put up on the site as long as I can do it in a non-commercial way.

The site is supported with donation from users, friends and selling of the Galaxy Service Manual CD to cover some of the costs of having this website on the Internet instead of relying on banner ads, pop-up ads, commercial links, etc. to pay my costs. Thus I do not accept advertising banners or pop-up/pop-under advertising or other marketing/sales links or gimmicks on my website.

ALL the money from donations is used for CBTricks.com I didn't do all the work to make money (I have a day job). I all didn't do all this work for someone else to make money also, for example the ebay CD sellers.

All Trademarks, Logos, and Brand Names are the property of their respective owners. This information is not provided by, or affiliated in any way with any radio or antenna Manufacturers. Thank you for any support you can give.

Component Outline, Main P.C. Model 2702A

WIRING CHART MAIN P.C. BOARD

PIN NO.	WIRING CONNECTION
1	red wire to DC Power Supply jack
2	black wire to DC Power Supply jack
3	blue wire to external speaker
4	yellow wire to speaker
5A and 5B	no wire
6A	no wire
6B	white/orange wire to meter
7	white wire to Squeich switch
8	no wire
9	yellow wire to Squelch switch
10 thru 12	no wire
13	brown wire to pin 2 on Mic jack
14 thru 18	no wire
19	blue wire to on/off switch
20	red wire to on/off switch
21	purple wire to Squelch switch
22	one green wire to Squelch switch
· · ·	one green wire to pin 1 on Mic jack
23	white wire to PA jack
	yellow wire to pin 32 on Main P.C. board
24	red wire to light on meter
25	orange wire to on/off switch
26	pink wire to PA jack
27	blue wire to Squelch switch
28	no wire
29	brown wire to ANL switch
30 and 31	no wire
32	yellow wire to pin 23 on Main P.C. board
33	no wire
34	blue wire to pin 4 on Mic jack
35	gray/white wire to PA jack
36	no wire
37	red wire to Squelch switch
38	orange wire to RF Gain switch
40	red wire to on/off switch
1	white wire to light on meter
1	





Figure 4-1. Component Outline, Main P.C. Board, Model 2702A

Component Outline Channel Selector P.C. Board, Model 2702A




NOTES:

1. P.C. Board shown as viewed from component side.

2. Dashed outline component - mounted on foil side.

Figure 4-2. Component Outline, Channel Selector P.C. Board, Model 2702A

Component Outline LED Display P.C. Board, Model 2702A



1. P.C. Board shown as viewed from component side.

2. Dashed outline components - mounted on foil side.

Figure 4-3. Component Outline, LED Display P.C. Board, Model 2702A

Parts List

Main P.C. Board

Reference Designator	Description	Part No.
	main p.c. board assy completemain p.c. board drilled and plated	
NOTE: all capacitors are	50V ceramic disc unless otherwise noted.	
C101 C102 C103 C104 C105 C106 C107 C108 C109 C110 C111 C112 C113 C114 C115 C116 C17 C118 C116 C17 C120 C121 C122 C123 C124 C125 C126 C127 C128 C129 C130 C131 C132 C133 C134 C135 C136 C137 C138 C139 C130 C131 C132 C128 C129 C130 C131 C132 C134 C135 C136 C137 C138 C139 C140 C141 C142 C125 C126 C127 C128 C129 C130 C131 C132 C134 C135 C136 C137 C138 C139 C144 C135 C136 C137 C138 C139 C144 C145 C155 C156 C157 C158 C155 C156 C157 C158 C157 C158 C156 C157 C158 C157 C158 C156 C157 C158 C157 C158 C156 C156 C157 C158 C156 C156 C157 C158 C156 C157 C158 C156 C157 C158 C156 C157 C158 C156 C156 C166 C167 C166 C167 C168 C167 C168 C167 C168 C167 C168 C167 C168 C167 C166 C167 C168 C167 C166 C167 C167	22 pF 22 pF 22 pF 30 pF 10 uF, 16V 10 uF, 25V 330 pF 330 pF 230 pF 230 pF 22 uF 10 pF 10 uF 10 pF 10 pF 10 uF 10	72A403 72A403 72A403 72A434 72A451 72A451 72A451 72A440 72A416 72A416 72A416 72A426 72A426 72A426 72A426 72A420 72A420 72A420 72A420 72A420 72A420 72A420 72A420 72A420 72A420 72A420 72A440 72
C171 C172	047 uF, 50V, mylar .047 uF, 50V, mylar	72A443 72A443

Reference Designator	Description	Part No.
C174 C175 C176 C177 C178 C178 C179 C180	33 uF, 25V, electrolytic	72A425 72A430 72A428 72A408 72A408
C181 C182	100 pF	
C183 C184 C185 C186 C187 C188 C189 C190 C191 C192 C193	10 UF, 16V, electrolytic 47 UF, 10V, electrolytic not used not used 01 UF .01 UF	72A427 72A436 72A440 72A440 72A427 72A414
CF101	ceramic filter	78A067
CH101	choke coil	72A482
CT101	3.3-18 pF ceramic trimmer	72A439
D101 D102 D103 D104 D105 D106 D107 D108 D108 D109 D110 D111 D112 thru D113 D114 D115 D116 D116 D117 D118 IC101 IC102	SMV1334 varactor diode 1N751A zener diode 1N757A zener diode 1N4002 rectifier 1N4002 rectifier 1N4148 diode 1N4148 diode 1N60 diode 1N60 diode	76A134 76A132 76A132 760037 760037 760037 760037 760037 760037 760037 760057 760057 760057 760057
L101 L102 L103 L104 L105	TA7205P rf choke	72A490 72A481 72A480
L106 L107 L108	rf coil rf choke rf choke	
L108		
L108 L109 L110 L111 L112 L113 L114 L115 L116	rf coil rf coil rf coil transformer rf choke rf choke rf choke rf choke rf coil	72A484 72A485 72A491 73A041 72A488 72A488
Q101 Q102 Q103 Q104 Q105 Q106 Q107 Q108 Q109 Q110	MPS3704 MPS6514 MPS6513 MPS6513 MPS6513 MPS3704 MPS3704 MPS3702 MPS6513 MPS6513 MPS6513	76A142 76A140 760139 760139 760139 76A142 76A141 760139 760139

-36-

Reference Designator	Description	Part No.
Q111	MPS6513	
Q112	MPS-U02	
Q113	MRF-472	76A144
Q114	MPS6514	764140
Q115	MPS6514	764140
Q116	MPS6513	760120
Q117	MP96513	760100
Q118	MPS6513	704140
Q119	MPS6514	
	MPS6514	
Q120	MPS5172	
Q121	MPS6514	
Q122	MPS6513	
Q123	MPS6513	
Q124	MPS6513	
Q125	2N5088	
Q126	2N5088	
NOTE: All resistors	are ¼W, 10%, carbon film unless otherwise noted	
R101	330	
R102	100k	724612
R103	3.3k	
R104	1.5k	724568
R105	220k	704600
R106		
R107	1.5k	
	100k	
R108	1.5k	·····.72A568
R109	100k	72A612
R110	2.2k	
R111	lk	
R112	100k	
R113	3.3k	724576
R114	470	724556
R115	22k	72A330 70AE00
R116	470	
R117	470	
	33k	
R118	100, 1/2w, 10%, carbon film	72A717
R119	3.3k	
R120	100k	72A612
R121	2.2k	
R122	1k	
R123	2.2k	
R124	270	
R125	10k	
R126	not used	······································
R127	68	701506
R128	100	······
R129	100	······
R129 R130	220	
	47	
R131	10, ½w, 5%, carbon film	72A693
R132	47k	
R133	1K	72A564
R134	680	
R135	1.5k	
R136	100	
R137	1.8k, ¼w, 5%, carbon film	
R138	1k	
R139	470	724556
R140.	100k	79AA19
R141	1k	704564
R142	4.7k	
R143	470	
R144	470	
R145	47k 220 1/w 5% corbon film	·····
R145	220, ¼w, 5%, carbon film	
R140	330	·····
R147 R148	1.5k	·····/2A568
R140 R149	27k	····· /2A598
	220, ¼w, 5%, carbon film	·····
R150	47, ¼w, 5%, carbon film	····· /2A532
R151	22K	72A596
R152	270k	····.72A622
R153	47k	
R154	68k	72A608
R155	33k	72A600
R156	47k	72A506
R157	not used	
R158	100k	72A612
R159	1.5k	72A568
R160	1.5k	
R161	22, 1/2w, 5%, carbon film	
	11/	704504
R162 R163	1k 390	· · · · · · · · · · · / 2A304

-37-

Reference Designator	Description	Part No.
R164 R165 R166	10k	
R165 R167 R167 R168 R170 R171 R172 R173 R174 R175 R176 R177 R178 R177 R178 R179 R180 R181 R181 R182 thru R185	not used 27k 3.3k 220k 22k 150 2.2k 820 68 10k 82 270 680 22k 1.8k 1.8k 18k	.72A598 .72A576 .72A520 .72A596 .72A544 .72A572 .72A536 .72A538 .72A538 .72A538 .72A538 .72A550 .72A550 .72A550 .72A550
R185 R186 R187 R189 R190 R191 R192 R193 R194 R195 R196 thru R201 R202 R203 R204	not used 10k, ¼w, 5%, carbon film 820k, ¼w, 5%, carbon film 820k, ¼w, 5%, carbon film 220k, ¼w, 5%, carbon film 22k, ¼w, 5%, carbon film 10k, ¼w, 5%, carbon film 15k, ¼w, 5%, carbon film 15k, ¼w, 5%, carbon film 18k	.722634 .722634 .722630 .722580 .722586 .722588 .722588 .722588 .722568
RV101 RV102 RV103	10k 2k 20k, 30%, 0.1w trimmer	72A397
T101 T102 T103 T104 T105 T106 T107 T108 T109 T110 T111	37 mhz transformer 27 khz transformer 27 khz transformer 27 mhz transformer 27 mhz transformer 10.7 mhz transformer 455 khz transformer 455 khz transformer 455 khz transformer 455 khz transformer 25 khz transformer 27 mhz transformer	73A042 73A043 73A044 73A044 73A045 73A041 73A038 73A039 73A040 73A048
X101 X102 X103	11.8066 mhz crystal 11.695 mhz crystal 10.24 mhz crystal	.78A069

Led Display P.C. Board (A-1)

Description	Part No.
LED p.c. board assy complete LED p.c. board drilled and plated dual LED readout TLR320 1.8k, ½w, 5%	.879560 .750267 .760331
1.8k, ½w, 5% carbon film	. 722570

Channel Selector P.C. Board (A-2)

Reference Designator

S1

Reference Designator

R1 thru R4 R1 thru R14

DescriptionPart No.channel selector switch assy complete879561channel selector p.c. board drilled and plated75026640 channel switch w/LED pgm700067ribbon, p.c. board connector, 15 pin690100bushing, channel selector switch380347

-38-

Chassis Mounted Components

Reference Designator	Description	Part No.
C1 C2 C3 C4 C5 C6 C7 C8 C9 C10 C11 C12	330 pF, 500V, ceramic disc	721681 72A849 72A849 72A849 72A849 72A849 72A849 72A849 72A849 72A849 72A849
F1	2A fusein pw	r cord assy
J1 J2 J3 J4 J5 J6	jack, antenna jack, microphone 5 pin jack, ext. speaker jack, pa jack, ext. squelch jack, power connector 3 pin	650113 650076 650076 650102
L1	.18 uh coil	722871
M1	meter	790200
PL1	lamp, 6V, .04A	710039
R1	100k, ¼w, 10% carbon film	72A612
RV1 and RV2 RV3 RV4 RV5 RV6	not used 100k, 30%, 1W, dpdt 10k, 30%, 1W, dpdt not used 50k, 20%, spst	722908
SW1 S2 S3	switch, spst switch, toggle switch 10k/100k, 30%, .1W, dpdt	700066 722908
	speaker	730057

MECHANICAL PARTS

Part No.	Description	Qty
380350 380291 460100 460101	bracket, hanger bracket, meter supporting case, bottom case, top	1 1
879566 380293 380358 460189	chassis assy, main chassis clip, pwr conn. retention channel selector insert	1 1 1
879564 460145 460190 460108	escutcheon assy . front pannel insert . front panel . knob, channel selector switch	1 1 1
460196 460197 450197 460195	knob, inter concentric knob, outer concentric knob, volume and squelch	1 1 1

ACCESSORY PARTS

Part No.	Description	Qty
879569 879544 350629 879567 530017	parts package microphone, black CB holder, microphone dc power cord assy screw, thumb	.1 .1

HY-GAIN DE PUERTO RICO, INC.

P.O. Box 68 State Hwy 31, Km. 4.0 Naguabo, Puerto Rico 00718