

Figure 21 – Main Printed Circuit Board Except 14T305




Figure 22 – Main Printed Circuit Board 14T305 only




Figure 23 – Lamp Printed Circuit Board – 14T270




Figure 24 – SWR Printed Circuit Board – 14T270 & 14T305




Figure 25 – SWR & MOD Meter Printed Circuit Board – 14T303




Figure 26 – Channel Selector Printed Circuit Board – 14T303




Figure 27 – LED Printed Circuit Board – 14T303




Figure 28 – Power Supply Printed Circuit Board – 14T303




Figure 29 – LED Printed Circuit Board – 14T304




Figure 30 – Channel Selector Printed Circuit Board – 14T304




Figure 31 – LED Printed Circuit Board – 14T305





Figure 32 – Microphone Jack Printed Circuit Board – 14T305



E : EMITTER  
C : COLLECTOR  
B : BASE




Figure 33 – Semiconductor Terminal Connections