

This Manual is provided by
CBTricks.com

Someone who wanted to help you repair your equipment
scanned this manual.

If you would like to help us put more manuals online support us.

Supporters of CBTricks.com paid for the hosting so you would have this file.

CBTricks.com is a non-commercial personal website was created to help promote the exchange of service, modification, technically oriented information, and historical information aimed at the Citizens Band, GMRS (CB "A" Band), MURS, Amateur Radios and RF Amps.

CBTricks.com is not sponsored by or connected to any Retailer, Radio, Antenna Manufacturer or Amp Manufacturer, or affiliated with any site links shown in the links database. The use of product or company names on my web site is not endorsement of that product or company.

If your company would like to provide technical information to be featured on this site I will put up on the site as long as I can do it in a non-commercial way.

The site is supported with donation from users, friends and selling of the Galaxy Service Manual CD to cover some of the costs of having this website on the Internet instead of relying on banner ads, pop-up ads, commercial links, etc. to pay my costs. Thus I do not accept advertising banners or pop-up/pop-under advertising or other marketing/sales links or gimmicks on my website.

ALL the money from donations is used for CBTricks.com I didn't do all the work to make money (I have a day job). This work was not done for someone else to make money also, for example the ebay CD sellers.

All Trademarks, Logos, and Brand Names are the property of their respective owners.
This information is not provided by, or affiliated in any way with any radio or antenna Manufacturers.
Thank you for any support you can give.

COBRA 28 PARTS LIST

530-028-0-000

SCHEMATIC SYMBOL	DESCRIPTION	DYNASCAN PART NO.
RESISTORS, CONTROLS, AND THERMISTORS		
R102	Semi-Fixed 1K Ohms	008-158-9-001
R48	Semi-Fixed 20K Ohms	008-158-9-002
R19	Semi-Fixed 100K Ohms	008-158-9-003
R73	Semi-Fixed 200K Ohms	008-158-9-004
R51	Variable 5K Ohms	008-158-9-005
R38	Variable 20K Ohms	008-158-9-006
R88	Variable 50K Ohms	008-158-9-007
R69	Thermistor D22A	004-099-9-001
R49	Thermistor D33A	004-099-9-002

CAPACITORS & TRIMMERS

C8	Ceramic NPO 1pF, 50V	031-030-9-001
C13, 54, 55	Ceramic NPO 2pF, 50V	031-030-9-002
C6, 11	Ceramic NPO 5pF, 50V	031-030-9-003
C50	Ceramic NPO 7pF, 50V	031-030-9-004
C17, 51	Ceramic NPO 10pF, 50V	031-030-9-005
C36, 37, 41, 48	Ceramic N220 47pF, 50V	030-088-9-002
C65	Ceramic N220 68pF,	020-088-9-001
C40, 47, 68, 69	Ceramic N220 100pF, 50V	020-088-9-003
C105, 106	Ceramic N470 180pF, 50V	020-088-9-005
C107, 108	Ceramic N750 470pF, 50V	020-088-9-011
C81, 87, 103, 104	Ceramic YW 470pF, 50V	020-088-9-006
C 1, 4, 5, 7, 9 25, 34, 43, 61 70, 78, 82, 88	Ceramic YR 2200pF, 50V	020-088-9-007
C 2, 10, 12, 14, 16, 23 29, 30, 31, 32, 33, 38 39, 42, 49, 52, 53, 56 57, 58, 59, 60, 64, 66 90, 94, 95, 96, 97, 98 99, 109, 110	Ceramic YR 4700pF, 50V	020-088-9-008
C26, 74, 75, 84	Ceramic YR 10000pF, 50V	020-088-9-009
C63	Ceramic Variable 30pF, 50V	020-088-9-010
C102	Mylar Film 6800pF, 50V	025-060-9-002
C85	Mylar Film 0.01 μ F, 50V	025-060-9-001
C18, 19, 24, 44, 77	Mylar Film 0.033 μ F, 50V	025-060-9-003

COMPOSITE
499-032-9-001

SCHEMATIC SYMBOL	DESCRIPTION	DYNASCAN PART NO.
---------------------	-------------	----------------------

CAPACITORS & TRIMMERS (Continued)

C3	Mylar Film 0.1 μ F, 50V	025-060-9-004
C73, 91	Tantalum 33 μ F, 50V	027-005-9-001
C100, 101	Electrolytic 1 μ F, 16V	022-076-9-001
C15, 21, 27, 89	Electrolytic 3.3 μ F, 16V	022-076-9-002
C35, 71, 79, 86	Electrolytic 10 μ F, 16V	022-076-9-003
C45	Electrolytic 33 μ F, 6.3V	022-076-9-004
C28, 46, 83, 93	Electrolytic 33 μ F, 16V	022-076-9-005
C92	Electrolytro 100 μ F, 16V	022-076-9-006

COILS, CHOKES, AND TRANSFORMERS

T1	RF Transformer L1640	066-013-9-001
T2, 3	RF Transformer L1641	066-013-9-002
T4, 5	RF Transformer L1643	066-013-9-003
T6	IF Transformer DI0764	060-014-9-001
T7	IF Transformer DI0765	060-014-9-002
T8	IF Transformer DI0766	060-014-9-003
T9	IF Transformer DI0753	060-014-9-004
T10	RF Transformer L1645	066-013-9-004
T11	RF Transformer L1644	066-013-9-005
T12	RF Transformer L1503	066-013-9-006
T13	RF Transformer L1504	066-013-9-007
T14	RF Transformer L1500	066-013-9-008
T15, 16	RF Transformer L1505	066-013-9-009
T17	RF Transformer L1511	066-013-9-010
T18	RF Transformer L1512	066-013-9-011
T19	AF Driver Transformer	068-005-9-001
T20	AF Output Transformer	061-017-9-001
L1	Delta Tune L1646	044-025-9-001
L2, 3	RF Choke Coil L1122	042-009-9-001
L4	RF Output L1101	044-025-9-002
IC1	TA7061P	307-007-9-001

DIODES, TRANSISTORS, AND INTEGRATED CIRCUIT

IC2	TA7062P	307-007-9-002
Q1, 4, 5, 6, 7 9, 10, 11, 12 13, 14, 15, 19 26, 29, 30, 31 32, 33, 34, 35 36, 37, 38, 39 40, 41, 42, 43	} 2SC372 Silicon NPN	176-029-9-001

SCHEMATIC
SYMBOL

DESCRIPTION

DYNASCAN
PART NO.

DIODES, TRANSISTORS, AND INTEGRATED CIRCUIT

Q3	2SC784	Silicon NPN	176-026-9-001
Q2	2SK19	FET	182-009-9-001
Q8, 21	2SA495	PNP Silicon	177-006-9-001
Q16	2SC735	NPN Silicon	176-031-9-001
Q17	2SC482	NPN Silicon	176-029-9-002
Q18	2SC517	NPN Power Silicon	172-009-9-001
Q22, 23	2SC732	NPN Silicon	176-031-9-002
Q24, 25, 27	2SD235	Power	172-010-9-001
Q20, 28	2SA562	PNP Small Signal	177-006-9-002
CD1, 5, 6, 11 12, 16, 17 22, 23, 24 25, 26, 27 28, 29, 30, 32	1S1555		
.....				
.....				
.....				
.....				
CD2, 3	1S2091151-030-9-002		
CD4	1N60150-001-9-005		
CD21, 31	S3004-1715151-030-9-003		
CD7	1S1658151-030-9-004		
CD13, 14, 15, 19, 20	1S1885151-030-9-005		
CD9, 10, 18	S3016R151-030-9-006		
CD8	S3004-1718151-031-9-001		

CRYSTALS

X1	Crystal	16.965 MHz	133-002-9-001
X2	Crystal	17.015 MHz	133-002-9-002
X3	Crystal	17.065 MHz	133-002-9-003
X4	Crystal	17.115 MHz	133-002-9-004
X5	Crystal	17.165 MHz	133-002-9-005
X6	Crystal	17.215 MHz	133-002-9-006
X7	Crystal	9.545 MHz	133-002-9-007
X8	Crystal	9.555 MHz	133-002-9-008
X9	Crystal	9.565 MHz	133-002-9-009
X10	Crystal	9.585 MHz	133-002-9-010
X11	Crystal	10.000 MHz	133-002-9-011
X12	Crystal	10.010 MHz	133-002-9-012
X13	Crystal	10.020 MHz	133-002-9-013
X14	Crystal	10.040 MHz	133-002-9-014

SWITCHES

S1, 2, 5, 6	Slide Switch	4C-2P	084-023-9-001
S3	Rotary Switch	24 steps	083-121-9-001

SCHMATIC
SYMBOL

DESCRIPTION

DYNASCAN
PART NO.

MISCELLANEOUS

K1	Relay 4C-2P	441-006-9-001
M1	DC Ammeter 200 μ A	320-035-9-001
MK1	Dynamic Microphone	562-003-9-001
PL1, 3, 4	Indicator Lamp	400-022-9-001
PL2	Indicator Lamp	400-022-9-002
SP1	Speaker 2 $\frac{1}{2}$ ", 8 Ohms	580-009-9-001
U1	Ceramic Filter	140-006-9-001
	Knob for channel switch	751-082-9-001
	Knob for volume, delta tune and squelch	751-082-9-002
	Channel indicator	380-153-9-001
	Sub panel for volume and squelch	754-015-9-001
	Sub panel for channel switch and delta tune	254-015-9-002
	Speaker holder	251-088-9-001
	Kit, Screws and nuts	763-015-9-001
	Meter Holder	251-089-9-001

NOTE: Standard value resistors and capacitors are not listed, values may be obtained from schematic diagram.

Minimum charge \$2.00 per invoice. Orders will be shipped C.O.D. unless previous open account arrangements have been made or remittance accompanies order. Advance remittance must cover postage or express charge.

Specify serial number when ordering replacement parts.