

| | PAGE |
|---|------|
| CHAPTER 1 Introduction | |
| 1.0 Introduction: | 1 |
| 1.1 Specifications: | 1 |
| CHAPTER 2 Operation | |
| 2.0 Installation: | 2 |
| 2.1 Operation: | 3 |
| CHAPTER 3 Circuit Description: | |
| 3.0 Introduction: | 5 |
| 3.1 High Voltage Supply: | 5 |
| 3.2 Screen and Bias Supplies: | 6 |
| 3.3 Low Voltage Supply: | 6 |
| 3.4 R.F. Input and Control: | 7 |
| 3.5 Safety Interlock: | 9 |
| 3.6 Wattmeter: | 9 |
| CHAPTER 4 Maintenance | |
| 4.0 Plate Current Measurement: | 10 |
| 4.1 Bias Voltage Adjustment: | 11 |
| 4.2 Wattmeter Calibration: | 12 |
| 4.3 Input SWR Adjustment: | 12 |
| 4.4 Voltage Checks: | 13 |
| 4.5 Preventive Maintenance: | 13 |
| 4.6 Tube Replacement: | 14 |
| CHAPTER 5 PCB Layouts | |
| 5.0 Low Voltage Supply PCB: | 15 |
| 5.1 High Voltage Supply PCB (Board #1): | 16 |
| 5.2 High Voltage Supply PCB (Board #2): | 17 |
| 5.3 Wattmeter PCB: | 18 |
| 5.4 RF Input and Control PCB: | 19 |
| 5.5 Safety Interlock PCB: | 20 |
| 5.6 PCB Trace Layouts: | 21 |
| PCB Trace Layouts (Cont.): | 22 |
| 5.7 Chassis Layouts Front and Rear: | 23 |
| 5.8 Chassis Layouts Top and Bottom: | 24 |
| CHAPTER 6 Parts Lists | |
| 6.1 High Voltage Power Supply PCB #1: | 25 |
| 6.2 High Voltage Power Supply PCB #2: | 26 |
| 6.3 Safety Interlock PCB: | 26 |
| 6.4 Low Voltage Power Supply PCB: | 27 |
| 6.5 RF Input and Control PCB: | 28 |
| 6.6 Wattmeter PCB: | 29 |
| 6.7 Chassis: | 29 |
| Chassis (cont.): | 30 |

CHAPTER 7 Circuit Modifications

| | | |
|-----|--|----|
| 7.0 | Introduction: | 31 |
| 7.1 | Screen LED Modification: | 31 |
| 7.2 | Screen Supply Modification: | 31 |
| 7.3 | Tube Oscillation: | 31 |
| 7.4 | Wattmeter PCB Modification: | 31 |
| 7.5 | Bias Circuit Modification Version 1: | 32 |
| 7.6 | Bias Circuit Modification Version 2: | 32 |

CHAPTER 8 Component Information

| | | |
|-----|---|----|
| 8.0 | Introduction: | 33 |
| 8.1 | Antenna Change Over and Preamp Relay Information: | 33 |
| 8.2 | Band Switch: | 33 |
| 8.3 | Input Coil Detail: | 33 |
| 8.4 | Z1 Detail: | 33 |
| 8.5 | Z2 Detail: | 33 |
| 8.6 | Blower Detail: | 34 |
| 8.7 | Part Suppliers: | 34 |
| | Nomad Radio Replacement HV Power Supply Kit Information | 35 |

CHAPTER 9 Schematics

| | | |
|-----|-------------------------------------|----|
| 9.0 | Introduction: | 36 |
| | Main Schematic: | 37 |
| | Power Supplies: | 38 |
| | RF Section: | 39 |
| | Inter-Connection Diagram: | 40 |